

Preventive Maintenance for 5700							
Operations	Maintenance Period						Labor Time
	3.000 drinks or 1 month	10.000 drinks or 3 months	20.000 drinks or 6 months	40.000 drinks or 1 year	80.000 drinks or 2 years (1)	160.000 drinks or 4 years (1)	
Remove, brush and wash the coffee group. Grease the movement screw.	X						20 min
Do the Monthly Cleaning as described on the Cleaning Table of the Instructions Manual (par. 4.2)	X						30 min
Check the fresh milk inlet pipe and change if necessary	X						5 min
Check the fresh milk inlet filter and change if necessary	X						5 min
Check the fresh milk outlet pipe and change if necessary	X						5 min
Check products doses and adjust if necessary			X				10 min
Clean drain tray and tube	X						10 min
Clean bean hopper	X						10 min
Replace coffee group O-rings		X					10 min
Replace mixing bowls O-rings		X					10 min
Check the grinder adjustment and ground coffee quantity. Adjust if necessary		X					20 min
Check the milk foam and adjust air regulators if necessary		X					15 min
General machine cleaning	X						20 min
Check the drip tray presence switch			X				5 min
Check the drip tray float switch			X				5 min
Check the door switch			X				5 min
Check the cup station LEDs			X				5 min
Check the cup sensor			X				5 min
Check for leaks		X					10 min
Check and clean the coffee chute and the grinders funnels			X				5 min
Check and clean the detergent tank(s)				X			5 min
Replace the modules nozzles O-rings and grease the nozzles				X			15 min
Check and clean the boiler assembly				X			20 min
Replace the grinder blades				X			10 min
Replace the coffee group filters				X			20 min
Replace the powder motors					X		20 min
Replace the whipper motors					X		20 min
Replace the main inlet valve					X		15 min
Replace the flow meter						X	15 min
Replace the boiler module						X	25 min
Replace the grinder module						X	25 min
Replace the milk module						X	25 min
Replace the pump module						X	20 min
Replace the coffee group				X			5 min
Replace the coffee group gear motor						X	20 min

(1) - 2 Year and 4 Years maintenance is only suggested